## ■Connectable indoor unit list (For Europe Regulation (Lot6))

•This outdoor unit / heat source unit can be connected to these indoor units as shown below.

Туре		Model name	Connectable series						
			VRF				HVRF		
			PUHY	<b>PURY</b>	PQHY	<b>PQRY</b>	PUHY	<b>PURY</b>	<b>PQRY</b>
Ceilling Cassette	4-way air flow	PLFY-P VBM*	0	0	0	0			
		PLFY-(E)P VEM*	0	0	0	0			
		PLFY-P VFM*	0	0	0	0			
	2-way air flow	PLFY-P VLMD*	0	0	0	0			
	1-way air flow	PMFY-P VBM*	0	0	0	0			
Ceilling Concealed		PEFY-P VMR*	0	0	0	0			
		PEFY-P VMS1(L)*	0	0	0	0			
		PEFY-P VMA(L)*	0	0	0	0			
		PEFY-P VMA*	0	0	0	0			
		PEFY-P VMH*	0	0	0	0			
		PEFY-P VMH(S)*	0	0	0	0			
	Fresh Air Intake	PEFY-P VMH(S)-E-F*	0	0	0	0			
Ceilling Suspended		PCFY-P VKM*	0	0	0	0			
Wall Mounted		PKFY-P VBM*	0	0	0	0		$\backslash$	
		PKFY-P VHM*	0	0	0	0			
		PKFY-P VKM*	0	0	0	0			
Floor Standing/		PFFY-P VKM*	0	0	0	0	$\setminus$	$\setminus$	
Floor Mounted Concealed		PFFY-P VLEM*	0	0	0	0			
		PFFY-P VLRM*	0	0	0	0			
		PFFY-P VLRMM*	00	0	0	0			
		PFFY-P VCM*	0	0	0	0			
Floor Standing		PWFY-(E)P VM* -AU	0	0	0	0	$\setminus$	$\setminus$	
-		PWFY-P VM* -BU		0	_	0			
Ceilling Concealed		PEFY-WP VMS1*	$\overline{}$	$\setminus$	$\setminus$		_	0	0
		PEFY-WP VMA*						0	0
		PEFY-W VMA(L)*					0	0	0
		PEFY-W VMS*					0	0	0
Ceiling cassette		PLFY-WP VBM*					_	0	0
<u> </u>		PLFY-WP VFM*					_	0	0
Floor standing		PFFY-WP VLRMM*					_	0	0
_		PFFY-W VCM*					0	0	0

Note: \* " means suffix such as letters or numbers.