■Connectable indoor unit list

•This outdoor unit can be connected to these indoor units as shown below.

Туре		Model name	Connectable series						
			VRF			HVRF			
			PUHY	PURY	PQHY	PQRY	PUHY	PURY	PQRY
Ceilling Cassette	4-way air flow	PLFY-P VBM*	0	0	0	0			
		PLFY-P VFM*	0	0	0	0			
		PLFY-(E)P VEM*	0	0	0	0			
	2-way air flow	PLFY-P VLMD*	0	0	0	0			
	1-way air flow	PMFY-P VBM*	0	0	0	0			
Ceilling Concealed	•	PEFY-P VMR*	0	0	0	0			
		PEFY-P VMS1(L)*	0	0	0	0			
		PEFY-P VMA(L)*	0	0	0	0			
		PEFY-P VMA*	0	0	0	0			
		PEFY-P VMH*	0	0	0	0			
		PEFY-P VMH(S)*	0	0	0	0			
	Fresh Air Intake	PEFY-P VMH(S)-E-F*	0	0	0	0			
Ceilling Suspended		PCFY-P VKM*	0	0	0	0			
Wall Mounted		PKFY-P VBM*	0	0	0	0			
		PKFY-P VHM*	0	0	0	0			
		PKFY-P VKM*	0	0	0	0			
Floor Standing/		PFFY-P VKM*	0	0	0	0			
Floor Mounted Concealed		PFFY-P VLEM*	0	0	0	0			
		PFFY-P VLRM*	0	0	0	0			
		PFFY-P VLRMM*	0	0	0	0			
		PFFY-P VCM*	0	0	0	0			
Floor Standing		PWFY-(E)P VM* -AU	0	0	0	0			
		PWFY-P VM* -BU	_	0	_	0			
Ceilling Concealed		PEFY-WP VMS1*					_	0	0
		PEFY-WP VMA*					_	0	0
		PEFY-W VMS*					0	0	0
		PEFY-W VMA(L)*					O	Ö	O
Ceiling cassette		PLFY-WP VBM*					_	Ö	Ö
		PLFY-WP VFM*						Ŏ	Ŏ
Floor standing		PFFY-WP VLRMM*					_	Ö	
		PFFY-W VCM*					0	Ö	0

^{* &}quot; means suffix such as letters or numbers.